

JAGUAR CROSSBAR INSTALLATION GUIDE

Only applicable to fixed connection bridge anchor

SPECIFICATION

Model year:	Naked rooftop with fixed connection bridge anchor on 2009-2010 Vibe or Matrix
Crossbar Length:	80cm, Range from 94cm to 100cm
Maximum load capacity:	75KGs/165LBs maximum weight capacity
	Refer to car user manual for the recommended limitation from factory.

PART LIST



PART INDEX	DESCRIPTION	QTY.
A	Aluminum bars	2
B	Driver/Left Brackets with Lock cover	2
C	Passenger/Right brackets with Lock cover	2
D	J-bolts	4
E	Key	2
F	Rubber Cushions	4

TOOLS RECOMMENDED (NOT INCLUDED)



Philip Screwdriver



10mm socket

TOOLS INCLUDED






Identify aluminum bars, brackets and other accessories at positions of Front Left, Front Right, Rear Left, and Rear Right. Wrong locating could result in failure of the assembling or installing.




Mount brackets to bars at the right end. Left side brackets are for driver sides, and right side brackets are for passenger sides. The Front aluminum bar is longer than the bar at rear mostly. Line up bottom of the bar edge to the entry bottom of the brackets, then push the bar into the bracket, loosening all bolts impacting the insertion if required.



Check assembled crossbars to be adjustable at this moment, DO NOT tighten all bolts until crossbars are mounted on the roof rails later. Tighten the 5 bolts in the center of the brackets with some tools.




Disclose the fixpoint mounting anchors on vehicle rooftop with a proper tool, clean the mounting hole area. Applying some waterproof tape might be recommended.



Slide the J-bolt hook from outside towards the inside to hold the bridge anchor. Place the crossbar over the J-bolt on the slot area aligning the hole. Install the washer and nut on the J-bolt.

Note: If the J-bolt is hard to hook on the bridge, unassemble the bolts, then insert the hook block, then mount the bolt from top after the rubber and brackets positioned on.



Mount the J-bolt with the small allen key to the mounting hole, try to fasten it securely. Put the assembled crossbars at the mounting position, longer one at the front, shorter one at the rear, thicker or flatter side of the bar faces forward, sharp or tape side of the bar faces backward.



Put the small screws back to the bar end after all bolts are fixed.



Put the cover back to the brackets. Using the thin narrow tool to push the strip down at the end of bar top slot and slide the tap at the downside of cover, then slide the cover along to put the cover into the bracket. Make the lock tone into the bracket locking hole before trying the lock the cover.

SUPPORT Visit https://rockautoaccs.com for more products Contact at rockmautox@gmail.com for any concerns or problems in Canada.	ROKIOTOEX will warranty all ROKIOTOEX brand car rack systems and its accessories manufactured by ROKIOTOEX during the time that an original retail purchaser owns the product. This warranty terminates if a purchaser transfers the product to any other person. Subject to the limitations and exclusions described in this warranty, ROKIOTOEX will remedy defects in materials or workmanship by repairing or replacing, at its option, a defective product without charge for parts or labor. In addition, ROKIOTOEX may elect, at its option, not to repair or replace a defective product but rather issue to a purchaser a refund equal to the purchase price paid for the product or a credit to be used toward the purchase of a new ROKIOTOEX load carrier system.	DISCLAIMER OF LIABILITY REPAIR OR REPLACEMENT OF A DEFECTIVE PRODUCT OR THE ISSUANCE OF A REFUND OR CREDIT (AS DETERMINED BY ROKIOTOEX) IS A PURCHASER'S EXCLUSIVE REMEDY UNDER THIS WARRANTY. DAMAGE TO A PURCHASER'S VEHICLE, CARGO AND/OR TO ANY OTHER PERSON OR PROPERTY IS EXCLUDED.
SAFETY NOTES Never Exceed the manufacture's roof rack load limit. Ensure load is evenly distributed between the two crossbars and that it is as low as possible refer to specification. Confirm lightness every 1000 km, periodically check that the load is secure and crossbars are securely tightened. Ensure that crossbar installed in correct orientation. Ensure that the crossbars are fully installation to the side supports with no gaps.	No warranty is given for defects caused by normal wear and tear, cosmetic rust, scratches, accidents, unlawful vehicle operation, or modification of, or any types of repair of, a load carrier system other than those authorized by ROKIOTOEX. No warranty is given for defects resulting from conditions beyond ROKIOTOEX's control including, but not limited to, misuse, overloading, or failure to assemble, mount or use the product in accordance with ROKIOTOEX's written instructions or guidelines included with the product or made available to the purchaser. No warranty is given for Rokioex products purchased outside of the United States, Canada and Mexico. In the event that a product needs to be returned to ROKIOTOEX, a ROKIOTOEX technician at the address or telephone number listed above will provide the purchaser with the appropriate mailing address and any additional instructions. Please note that the purchaser will be responsible for the cost of mailing the product to ROKIOTOEX and that proof of purchase in the form of an original purchase invoice or receipt and a detailed description of the defect must be included in the mailing.	THIS WARRANTY IS EXPRESSLY MADE IN LIEU OF ANY AND ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. ROKIOTOEX'S SOLE LIABILITY TO ANY PURCHASER IS LIMITED TO THE REMEDY SET FORTH ABOVE. IN NO EVENT WILL ROKIOTOEX BE LIABLE FOR ANY LOST PROFITS, LOST SALES, OR FOR ANY CONSEQUENTIAL, DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR PUNITIVE DAMAGES OR FOR ANY OTHER DAMAGES OF ANY KIND OR NATURE. SOME STATES DO NOT ALLOW THE EXCLUSION OR LIMITATION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE LIMITATIONS MAY NOT BE APPLICABLE. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS, AND YOU MAY ALSO HAVE OTHER RIGHTS WHICH VARY FROM STATE TO STATE.